


Overview

Instrument Panel




Windshield wiper and washer switch P.37

Rear window wiper and washer switch P.40

Engine (ignition) switch *1 P.21

Power (ignition) switch *2 P.22



Power back door main switch P.97

Remote Touch *3 P.41

Lexus Display Audio controller *4 P.44

Head-up display main switch * P.35

* : If equipped

*1: RX270/RX350

*2: RX450h

*3: With navigation system

*4: With Lexus Display Audio system

A

► Without a navigation system or Lexus Display Audio system



Air conditioning
system P.84

Audio system
P.77

A


► with the Lexus Display Audio system

Lexus Display
Audio system

P.44

Air conditioning
system

P.70



Audio system

P.63


► with a navigation system

Navigation system

P.45

Air conditioning
system

P.70



Audio system

P.63

* : If equipped


Overview

Instrument Panel

B

Steering wheel audio
switches P.63, 83

Telephone switch P.53, 72



Multi-information switches P.25, 27

Talk switch
P.53, 72, 85

Cruise control switch P.31, 32

Distance switch * P.32

* : If equipped